

► Escort Intelligent MINI Data Logger

available for purchase for your clinical trial.

Overview

The Escort Intelligent MINI data loggers are ideal for use when transporting samples, and offer a low cost alternative for solving your temperature monitoring problems. These loggers have internal or external sensor options, a large LCD display and a two Kilobyte memory which is capable of storing 1868 samples.

They record in real time and can be programmed to start on demand by a simple button press or with a start delay of 0 to 255 minutes. The Escort Intelligent MINI's electronics are housed within a robust ABS plastic case which fits discreetly into any package or consignment.

Specification

- Temperature Range: -40°C to +65°C
- Sensors: internal or external options
- Accuracy: $\pm 0.5^{\circ}\text{C}$
- Resolution: 0.1°C
- Memory: 1,868 samples
- Sensor Response Time: internal sensor T90 of 20 minutes in moving air (external sensor: 5 minutes)
- Sampling Frequency: 1 to 225 minutes
- Power Source: user replaceable 3.6V 550 mAh lithium coin battery
- Typical Battery Life: 1 to 2 years
- Weight: 70g including battery
- Dimensions: 83h x 57w x 20d mm

Operating Features

- Large LCD display with multi function viewing
- Available with either internal or external sensor options
- Customisable alarm settings and programmable start function
- Downloadable via a USB to Serial Port cable, no interface required
- Provide maximum data logging reliability and accuracy at a low cost
- User-friendly multi-language software for easy programming and download
- CE marked



Please contact us for a quotation for the purchase of this product.

Product description - Escort Intelligent MINI Data Logger
Product Code - WD7528



Tel: +44 (0) 8456 777001 | **Fax:** +44 (0) 8456 777002
Email: sales@woodleyequipment.com
www.woodleyequipment.com

WOODLEY
 EQUIPMENT COMPANY LTD.