

Digital Min/Max - Internal or External Thermometer

Available for hire or purchase for your clinical trial.



Overview

This digital min/max and indoor/outdoor thermometer features an easy to read dual display. It simultaneously displays both the in and the out as well as the max/min temperatures at the push of a button. The instrument also features a programmable, audible high/low alarm (remote probe only).

Powered by AAA battery it is supplied with a small, water resistant, detachable remote sensor probe with three metre PVC lead for outside temperatures. The thermometer is housed in an ABS case incorporating a foldaway stand and a keyhole slot for hanging on a wall.

Operating Features

- Simultaneously displays outdoor and indoor temperatures
- Programmable high and low temperature alarm
- Detachable outdoor probe supplied
- Temperature range -49.9 to +69.9°C

Specification

- Temperature Range Inside: -19°C to +69.9°C
- Temperature Range Outside: -49°C to +69.9°C
- Accuracy: $\pm 1^\circ\text{C} \pm 1$ digit
- Resolution: $\pm 1^\circ\text{C} / ^\circ\text{F}$ (switchable)
- Battery: 1.5 V AAA
- Battery Life: 1000 hours
- Sensor Type: Thermistor
- Display: Custom dual LCD
- Weight: 100g
- Dimensions: 97h x 65w x 20d mm



Please contact us for a quotation for the hire or purchase of this product

Product description: - Digital Min/max - Indoor Outdoor Thermometer

Product Code: -

Product specifications can be subject to change without prior notice. Version: V2 10/19

UK Office

t: +44 (0)8456 777001 f: +44 (0)8456 777002

USA Office

t: 1 800 471 9200 / 1 718 606 0516 f: 1 718 606 0955

e: hello@woodleytrialsolutions.com

www.woodleytrialsolutions.com

woodley
TRIAL SOLUTIONS

Woodley Trial Solutions is a division of Woodley Equipment Company