



► EZ-SmartLog™ Two USB Datalogger with LCD

available for purchase for your clinical trial.

Overview

This temperature data logger with high contrast LCD measures and stores up to 16,378 temperature readings over a -35 to +80°C (-31°F to +176°F) range.

The data logger is easy to use and the logging rate, start time and download of stored data can be carried out by plugging the data logger into a PC USB port and running the supplied software.

Specification

- Measurement Range: -35°C to +80°C (-31°F to +176°F)
- Logging Rate: 10 sec to 12 hour
- Alarm LED's: 9 alarm combinations
- Internal Resolution: 0.5°C (0.1°F)
- Accuracy: ±0.5°C to ±1.5°C (0.1°F to 0.3°F)
- Operating Temperature: -35°C to +80°C (-31°F to +176°F)
- Battery: 3.6V 1/2 AA replaceable lithium
- Battery Life: 1 year
- Dimensions: 119h x 21w x 25.3d mm

Operating Features

- USB interface for set-up and data download
- User-programmable alarm thresholds
- Status indication via red, green and orange LEDs
- High contrast LCD with 2 and half digit temperature display system
- Immediate, delayed and push to start logging
- Supplied with replaceable internal lithium battery (typically allows logging for 1 year)
- Supplied with Windows control software which is easy to install and allows the following parameters to be configured:
 - Logger name (up to 16 characters)
 - °C or °F
 - Logging rate (10s, 1m, 5m, 30m, 1hr, 6hr, 12hr)
 - High and low alarm levels
 - Start date and time
- (compatible with Windows 7,8,10)
- Data protection to IP67 when protective cap fitted



Please contact us for a quotation for the purchase of this product.

Product description - EZ-SmartLog™ Two USB Temperature Datalogger with LCD
Product code - WD7TEM010



UK Office

T: +44(0)8456 777001

F: +44(0)8456 777002

E: enquiries@woodleyequipment.com

USA Office

T: 1 800 471 9200 /1 718 606 0516

F: 1 718 606 0955

www.woodleyequipment.com

WOODLEY
EQUIPMENT COMPANY LTD.